
# **EPD105**

**User Manual** 



< For reference only, actual product may vary. Company has final interpretation rights.> Before installing and using the furniture, please read the user manual carefully and keep it for future reference!


# **Technical Specifications**

Product Dimensions	Exterior:1000x1000x2300mm Interior:869x900x2000mm		
Max. Load Capacity of Product	130KG	Max. Load Capacity of Tabletop	25KG
Sensor Device	Human Sensing Central Lighting System		
Ventilation System	Fresh Air Ventilation System		
Soundproofing Effect	Soundproofing Volume 25dB±5dB		
Charging device	The maximum power of the socket is 1000W The USB-A+USB-C total 65W fast charge		


### **Product List**

### **Accessory Pack List**

Note: The line drawings below are for reference only and may differ from the actual product in some cases. Please refer to the actual product for accuracy. If you find any missing tools or encounter installation issues, please contact customer service.




### Preparation before installation




Installation on carpet to prevent scratching

It is recommended to bring your own utility knife or scissors




Suggested to have a cross-head screwdriver or power drill ready





Suggested to have two or more people to collaborate on the installation


### Parts List


No.	Part	No.	Part
1	Roof x1	2	Top cover x4 (Label serial number 1, 2, 3, 4)
3	Main body of the frame x1	4	Upper glass door x1
(5)	Tabletop x1	6	Table support x2
7	Hinge decoration cover x1 (Label number 1)	8	Magnet trim strip x1 (Label number 2)
9	Decorative cover x2 (Label serial number 3, 4)	10	Inner side door handle x
11)	Outside door handle x 1	12)	Suction cup x2
(13)	Sealing strip x1	14)	Product power cord x1



















## Operation guide




Please make sure there are no obstructions blocking the movement of the meeting pod during the lifting process and ensure that the power cable length is sufficient for the meeting pod to move up and down.






- a. Press the "\( \simega\) " button to raise the pod the maximum height. and the current height will be displayed on the screen.
- b. Press the "∨" button to adjust the height of the pod.You can manually press and hold to lower it to the lowest position.
- c. During operation, you can press any key to stop the lifting process.

Reset Function:




- a. When at the lowest position, press and hold the" "button for 5 seconds or more to enter the reset state until the lifting system reaches the bottom and rebounds to a stop.
- b. When at the lowest position, press and hold the "V" button for 5 seconds or more to enter the reset state until the lifting system reaches the bottom and rebounds to a stop.
- Code Handling:




- a. If the display shows "**E01**" or "**E02**", allow the room to rest for at least 18 minutes before normal use.
- b. If other codes appear and there is no response when pressing the " v " button, please check the connection wire for any damage and ensure it is properly connected. Disconnect the power for at least 10 seconds, then reconnect the power. The display will show" ¬ 5 \cdot ", and then press and hold the " v " button to reset.
- c. If the pod still cannot function properly after performing the above operations, please contact customer service.


#### Use of the Switch




The maximum power of the socket is 1000W The USB-A+USB-C total 65W fast charge

#### Use of the Switch







Rotate left and right to adjust the ventilation speed

6



### **Precaution**



Please place it on a flat surface while using it.



Warning! Watch out for pinch hazards.



Do not sit or put pressure on the table. Please do not place heavy objects on it.



Danger! Do not play with frequent lifting and lowering.



The product is suitable for ages 7 and above.



Attention! Adults only should install, keep children away.



- 1.Power supply: AC100V-240V, frequency 50/60Hz.
- 2.Operating environment: Indoor, 0-40°
- 3.Before cleaning, make sure to unplug the power cord. Use a slightly damp cloth to wipe away surface dust, taking care not to let water drip into the internal components or damage the connection wires. Regularly check if screws are loose and tighten them if necessary.
- 4. The electrical box contains electronic components, metals, plastics, wires, etc. Dispose of it according to the environmental regulations of your country, not as regular household waste.
- 5.Before using the product, carefully inspect and ensure that it has been correctly installed. Use only the accessories provided by the manufacturer for installation. Leave adequate safety clearance when placing the product to avoid pinch hazards.
- 6.Before first use, familiarize yourself with all the functions and program settings of the product.
- Children are not allowed to play on this product. Certain unpredictable behaviors may result
  from children playing on the product, and the manufacturer will not be responsible for any
  resulting accidents.
- 8. Slight noises from the multi-belt or brake system caused by the structure will not affect the use of the equipment.
- 9. The use of corrosive or abrasive materials for cleaning equipment is prohibited. Make sure that the cleaning agents used will not contaminate the environment.
- 10. Children should not perform cleaning and user maintenance without supervision.
- 11. In case of power cord damage, it must be replaced by the manufacturer or relevant professionals to avoid injury.
- 12. Ensure that your operating environment is free of any potential hazards.
- 13. When moving the product, ensure that there are no items placed on the table, the drawers and doors are closed securely, screws are tightened, and the power plug is unplugged. Use at least 2 people for moving. If necessary, keep the original packaging for future transportation.
- 14.If repeated transportation is required, please retain the product's original packaging and store it properly for reuse during transportation.
- 15.It is prohibited to strike the glass with sharp tools.
- 16. Do not use 1000W high-power electrical appliances to prevent damage to electrical appliances.

### Waste disposal



This marking indicates that this product should not be disposed with other household wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

7