




ASSEMBLY INSTRUCTION








Warning:

1. The maximum static loading weight is 100KG and the dynamic loading weight is 5-8KG!
2. The desk can not lift up by itself at the first time after placing some times or temperature is too low , you have to give a little pull force by hands to help it lift up!
3. The desk have potential danger of tip-over if don't use it wisely, so children need to be accompanied by adult.






	Ax4			Bx16	M6x12MM
	Cx8	M6x25MM		Ex1	
	Fx1	4MM			

1



Warning Hands Pinching
Do not place your hand near the here.
The angle changes during the
installation will hurt you.



Do not cut off tape
before open frame.




Bx4



Fx1

2




X2




Ax4

3




Cx8



Fx1

4




Bx4



Fx1

5



Bx8




Fx1




Ex1

6




Operating Manual

< 15KG



Attention: it is recommended not to exceed a maximum of 15KG on desk top to allow for easy lifting.



Lift the paddle for lifting the table top.

Lift the paddle and press the table top for downward operation.